BACK

To Ignition SW
IG Terminal

Fuse

[A]

SW 1

[B]

Relay

Voltmeter

0

V

[C]

SW 2

Solenoid