2   3   4

* 1 : w/ Theft Deterrent System

ACC
IG1 1 B–Y
on SW

B–Y

B A J18(A), J19(B)
Junction
Connector
B B

6 2A

10A
ECU–IG&GAUGE

20 2S

2 IF3

B–Y

B–Y

R–L

B–Y

G–Y

G–B

G–B

G–Y

T22
Turn Signal Flasher

1   4   2   3
IG   +B   LR   LL

19 2S   18 2S

GND   EL   ER
7   5   6

LG

G–B

G–Y

3 2S   2 2S   3 2L   3 2M   2 2M   2 2L   3 2K   2 2K

G–B   G–Y   G–B   G–B   G–Y   G–Y   G–B   G–Y

12 BA1   7 BA1

25 2N

G–O

4

H 5
Hazard Warning
Signal SW

2

R

J22(A), J23(B)
Junction
Connector

A A

A B   A B

W–B   LG

Instrument Panel
Reinforcement RH
IE

12   13

TL   E   TR

LH

N

RH

Turn
Signal SW

C10
Combination
SW   11

A A J20(A), J21(B)
Junction
Connector
A B

W–B

Instrument Panel
Reinforcement Center
ID

W

24   25

LH   RH

22   C 8
Combination
Meter

B A J22(A), J23(B)
Junction
Connector
B B

W–B

Y

2   2   2   2

1   1   1   1

T12   T14   T15   T13
Turn Signal Lamp   Turn Signal Lamp   Turn Signal Lamp   Turn Signal Lamp
(Front LH)   (Front Side LH)   (Front Side RH)   (Front RH)

W–B   W–B   W–B   W–B

W–B   A A W–B   W–B
A
J 1
Junction
Connector
A
W–B

Left Side of the
Fender Apron
EB

Right Side of the
Fender Apron
EA

G–B   G–Y
1   1

R 4   R 5
Rear Combination   Rear Combination
Lamp (LH)   Lamp (RH)
Turn   Turn

G–Y   G–Y
W–B   W–B

3   3

W–B   W–B

W–B

8 BA1

W–B

A J15
Junction
Connector

Cowl Side
Panel LH
IG