
HOW TO USE THIS MANUAL

Each repair method description provided in Section RE of this manual comprises two pages, divided into 2 blocks (REMOVAL AND INSTALLATION) and includes illustrations to facilitate body repair.



A : REPLACEMENT PARTS AND METHOD

QUARTER PANEL (CUT)

- Replacement method
  - (ASSY) .... Assembly replacement
  - (CUT) ..... Major cutting (less than 1/2 of parts used)
  - (CUT-H) .... Half cutting (about 1/2 of parts used)
  - (CUT-P) .... Partial cutting (most of parts used)
- Replacement Parts


B : PARTS LOCATION

C : REMOVAL DIAGRAM

Describes in detail removal of the damaged parts involving repair by cutting.

D : REMOVAL GUIDE

Provides additional information to more efficiently help you perform the removal.



Ⓔ : **INSTALLATION DIAGRAM**
Describes in detail installation of the new parts involving repair by welding and/or cutting, but excluding painting.

Ⓕ : **INSTALLATION GUIDE**
Provides additional information to more efficiently help you perform the installation.

Ⓖ : **SYMBOLS**
See page IN-4.

Ⓗ : **ILLUSTRATION OF WELD POINTS**
Weld method and panel position symbols.
See page IN-5.