ABBREVIATIONS

The following abbreviations are used in this manual.

ABS = Anti-Lock Brake System
A/C = Air Conditioner
ADD = Automatic Disconnecting Differential
A/T = Automatic Transmission
COMB. = Combination
DIFF. = Differential
DLC3 = Data Link Connector3
ECT = Electronically Controlled Transmission
ECU = Electronic Control Unit
EFI = Electronic Fuel Injection
EGR = Exhaust Gas Recirculation
EVAP = Evaporative Emission
G.C.C. = Gulf Cooperation Council
IIA = Integrated Ignition Assembly
ISC = Idle Speed Control
LH = Left-Hand
LHD = Left-Hand Drive
M/T = Manual Transmission
O/D = Overdrive
RH = Right-Hand
RHD = Right-Hand Drive
SW = Switch
TEMP. = Temperature
VSV = Vacuum Switching Valve
w/ = With
w/o = Without
2WD = Two Wheel Drive Vehicles
4WD = Four Wheel Drive Vehicles