D RELAY LOCATIONS

② : Engine Room R/B	RHD Diesel : Engine Compartment Right (See Page 27)
	Except RHD Diesel : Engine Compartment Left (See Page 26, 27)

