Position of Parts in Engine Compartment

[RHD:3RZ-FE]

*1 : w/ 2-4 Select SW
*2 : w/o 2-4 Select SW

