ABBREVIATIONS

The following abbreviations are used in this manual.

ABS	=	Anti–Lock Brake System
A/C	=	Air Conditioner
ADD	=	Automatic Disconnecting Differential
A/T	=	Automatic Transmission
BACS	=	Boost Altitude Compensational Stopper
COMB.	=	Combination
DIFF.	=	Differential
DLC3	=	Data Link Connector 3
ECT	=	Electronically Controlled Transmission
ECU	=	Electronic Control Unit
EFI	=	Electronic Fuel Injection
EGR	=	Exhaust Gas Recirculation
EVAP	=	Evaporative Emission
G.C.C.	=	Gulf Cooperation Council
IIA	=	Integrated Ignition Assembly
ISC	=	Idle Speed Control
LH	=	Left–Hand
LHD	=	Left–Hand Drive
M/T	=	Manual Transmission
O/D	=	Overdrive
RH	=	Right–Hand
RHD	=	Right–Hand Drive
SRS	=	Supplemental Restraint System
SW	=	Switch
TEMP.	=	Temperature
VRV	=	Vacuum Regulating Valve
VSV	=	Vacuum Switching Valve
w/	=	With
w/o	=	Without
2WD	=	Two Wheel Drive Vehicles
4WD	=	Four Wheel Drive Vehicles

* The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.