D RELAY LOCATIONS

② : Engine Room R/B	RHD Diesel : Engine Compartment Right (See Page 9)
	Except RHD Diesel : Engine Compartment Left (See Page 8, 9)

