
# Position of Parts in Engine Compartment

## [RHD : 1RZ]




A 1 A/C Dual Pressure SW
A 2 A/C Magnetic Clutch
A10 Alternator
A11 Alternator

B 1 Back–Up Light SW
B 2 Brake Fluid Level Warning SW

C 2 Carburetor

F 5 Front Turn Signal Light and Clearance Light LH
F 6 Front Turn Signal Light and Clearance Light RH

H 5 Headlight LH
H 6 Headlight RH
H 9 Horn

I 6 IIA

J 1 Junction Connector
J 2 Junction Connector

O 1 Oil Pressure SW

S 2 Starter
S 3 Starter

V 2 Vacuum SW
V 9 VSV (Throttle Position Control)

W 1 Washer Motor
W 2 Water Temp. Sender
W 4 Wiper Motor