G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
A 1	A/C Dual Pressure SW	90980–11149
A 2	A/C Lock Sensor	90980–11016
	A/C Magnetic Clutch (Except 2KD–FTV)	90980–11271
	A/C Magnetic Clutch (2KD–FTV)	90980–11016
A 3	A/T Fluid Temp. SW (2KD–FTV)	90980–11025
	A/T Fluid Temp. SW (3RZ–FE)	90980–10706
A 4	ABS Actuator	90980–10891
A 5	ABS Actuator	90980–11413
A 6	ABS Speed Sensor Front LH	90980–11075
A 7	ABS Speed Sensor Front RH	
A 8	ADD Indicator SW	90980–11250
A 9	Air Flow Meter	90980–11317
A10	Alternator (Except 2KD–FTV)	90980–11349
	Alternator (2KD–FTV)	90980–11964
A11	Alternator (Except 1RZ)	90980–09212
	Alternator (1RZ)	90980–09201
A12	Auto Antenna Motor	90980–11074
A13	A/C Amplifier	90980–10801
A14	A/C SW	90980–11280
A15	A/C Thermistor	90980–10825
A16	A/C Volume SW	90980–10214
A17	ABS Deceleration Sensor	90980–11182
A18	ABS ECU	90980–11565
A19	ABS ECU	90980–11390
A20	ADD Control Relay	90980–10173
A24	Airbag Squib (Front Passenger's Airbag Assembly)	90980–11884
A25	Airbag Squib (Steering Wheel Pad)	90980–10850
A26	Ashtray Illumination	90980–00308
A27	Auto Antenna Control Relay	90980–10799
A28	ABS Speed Sensor Rear LH	90980–11467
A29	ABS Speed Sensor Rear RH	
A31	Accelerator Pedal Position Sensor (1KZ–TE, 5L–E)	90980–11232
	Accelerator Pedal Position Sensor (2KD–FTV)	90980–11144
A32	Accelerator Pedal SW	90980–10825
A33	A/C Lock Detection Amplifier	90980–10801
B 1	Back–Up Light SW	90980–11250
B 2	Brake Fluid Level Warning SW	90980–11207
B 3	Brake Vacuum Warning SW	90980–11252
B 4	Blower Motor	90980–10214
B 5	Blower Resistor	90980–10171
B 6	Blower SW	90980–10463
B 7	Buckle SW	90980–11212
C 1	Camshaft Position Sensor	90980–10947

Code	Part Name	Part Number
C 2	Carburetor	90980–11037
C 3	Check Connector (LHD 1RZ, 2L, 3L)	90980–11195
	Check Connector (3RZ–FE, 2RZ–FE, 1RZ–E, 2KD–FTV, 1KZ–TE, 5L–E)	90980–11323
C 4	Crankshaft Position Sensor	90980–11016
C 5	Cigarette Lighter	90980–10760
C 6	Cigarette Lighter Illumination	90980–11148
C 7	Circuit Opening Relay	82602–35150
C 8	Clock	90980–11013
C 9	Combination Meter	90980–11113
C10	Combination Meter	90980–11114
C11	Combination Meter	90980–11115
C12	Combination SW	90980–11594
C13	Combination SW (LHD, RHD Europe)	90980–11672
	Combination SW (RHD Excepr Europe)	90980–11671
C14	Combination SW	90980–11616
C15	Crankshaft Position Sensor	90980–11162
C16	Center Airbag Sensor Assembly	90980–11873
C17	Center Airbag Sensor Assembly	90980–11872
C18	Center Airbag Sensor Assembly	90980–11871
D 1	Detection SW (Transfer 4WD Position) (w/ 2–4 SELECT SW)	90980–11250
	Detection SW (Transfer 4WD Position) (w/o 2–4 SELECT SW)	90980–10581
D 2	Detection SW (Transfer L4 Position)	90980–11156
D 3	Daytime Running Light Relay	90980–10807
D 4	Diff. Lock ECU	90980–10801
D 5	Diff. Lock SW	90980–10631
D 6	Dim–Dip Light Relay	90980–10807
D 7	Diode (Door Courtesy)	90980–11608
D 8	Diode (Glow Plug)	
D 9	Diode (Idle–Up) (LHD General A/T 3RZ–FE,2RZ–FE)	90980–11608
	Diode (Idle–Up) (LHD General 3RZ–FE M/T)	90980–11071
D10	DLC3	90080–98010
D11	Door Courtesy SW Front LH (Double Cab)	90980–11097
	Door Courtesy SW Front LH (Regular Cab, Extra Cab)	90980–10433
D12	Door Courtesy SW Front RH (Double Cab)	90980–11097
	Door Courtesy SW Front RH (Regular Cab, Extra Cab)	90980–10433
D13	Detection SW (Rear Diff. Lock)	90980–11250
D14	Door Courtesy SW Rear LH	90980–11097
D15	Door Courtesy SW Rear RH	
D16	Door Key Lock and Unlock SW	90980–11245
D17	Door Lock Control SW	90980–11013

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
D18	Door Lock Motor Front LH	90980–11150
D19	Door Lock Motor Front RH	
D20	Door Lock Motor Rear LH	
D21	Door Lock Motor Rear RH	
D22	Door Speaker Front LH	90980–10935
D23	Door Speaker Front RH	
D24	Door Speaker Rear LH	
D25	Door Speaker Rear RH	
E 1	ECT Solenoid (2KD–FTV A/T)	90980–10891
	ECT Solenoid (3RZ–FE A/T)	90980–10919
E 2	Engine Oil Level Warning SW (Except 2KD–FTV M/T 2WD)	90980–10532
	Engine Oil Level Warning SW (2KD–FTV M/T 2WD)	90980–11235
E 3	Emission Control ECU	90980–10807
E 4	Engine and ECT ECU (A/T) (2KD–FTV, 1KZ–TE)	90980–11421
	Engine and ECT ECU (A/T) (3RZ–FE, 2RZ–FE, 1RZ–E, 5L–E)	90980–11390
	Engine ECU (M/T) (2KD–FTV, 1KZ–TE)	90980–11421
	Engine ECU (M/T) (3RZ–FE, 2RZ–FE, 1RZ–E, 5L–E)	90980–11390
E 5	Engine and ECT ECU (A/T) (2KD–FTV, 1KZ–TE)	90980–11476
	Engine and ECT ECU (A/T) (3RZ–FE, 2RZ–FE, 1RZ–E, 5L–E)	90980–11391
	Engine ECU (M/T) (2KD–FTV, 1KZ–TE)	90980–11476
	Engine ECU (M/T) (3RZ–FE, 2RZ–FE, 1RZ–E, 5L–E)	90980–11391
E 6	Engine and ECT ECU (A/T) (1KZ–TE)	90980–11637
	Engine and ECT ECU (A/T) (2KD–FTV)	90980–11586
	Engine and ECT ECU (A/T) (3RZ–FE, 2RZ–FE, 5L–E)	90980–11392
	Engine ECU (M/T) (1KZ–TE)	90980–11637
	Engine ECU (M/T) (2KD–FTV)	90980–11586
	Engine ECU (M/T) (3RZ–FE, 2RZ–FE, 5L–E)	90980–11392
E 7	Engine Speed Sensor	90980–11250
E 8	EGR Valve Position Sensor	90980–11143
E 9	Electric Driver Unit	90980–11592
E10	Electric Driver Unit	90980–11024
E11	ECT Pattern Select SW	90980–10601
E12	EDU Relay	82602–35150
E13	Engine and ECT ECU (A/T) (2KD–FTV)	90980–11637
	Engine and ECT ECU (A/T) (5L–E)	90980–11408
	Engine ECU (M/T) (2KD–FTV)	90980–11637
	Engine ECU (M/T) (5L–E)	90980–11408

Code	Part Name	Part Number
E14	Engine and ECT ECU (A/T)	90980–11638
	Engine ECU (M/T)	
F 1	Front Clearance Light LH	90980–11149
F 2	Front Clearance Light RH	
F 3	Front Side Turn Signal Light LH	90980–11162
F 4	Front Side Turn Signal Light RH	
F 5	Front Turn Signal Light and Clearance Light LH	90980–10216
F 6	Front Turn Signal Light and Clearance Light RH	
F 7	Front Turn Signal Light LH	90980–11019
F 8	Front Turn Signal Light RH	
F 9	Fuel Heater	90980–10928
F10	Fuel Sedimentary SW	90980–11003
F11	4WD Control ECU	90980–10848
F12	Fuel Pump	90980–10843
F13	Fuel Sender (w/ Fuel Warning Light)	82890–32030
	Fuel Sender (w/o Fuel Warning Light)	90980–10214
F14	First Gear Position SW	90980–10923
F15	Front Airbag Sensor LH	90980–11856
F16	Front Airbag Sensor RH	
F18	Fuel Temp. Sensor	90980–10737
F19	Fuel Pressure Sensor	90980–10845
G 1	Glow Plug	–
G 2	Glove Box Light	90980–11148
H 1	Headlight Beam Level Control Actuator LH	90980–11016
H 2	Headlight Beam Level Control Actuator RH	
H 3	Headlight Cleaner Motor and Washer Motor	90980–10140
H 4	Headlight Cleaner Relay	90980–10939
H 5	Headlight LH	90980–11314
H 6	Headlight RH	
H 7	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980–11028
H 8	Heated Oxygen Sensor (Bank 1 Sensor 2)	
H 9	Horn (Except 1KZ–TE)	90980–10619
	Horn (1KZ–TE)	90980–10359
H10	Hazard SW	90980–10801
H11	Headlight Beam Level Control SW	90980–11280
H12	Headlight Cleaner SW	90980–10601
	Washer Motor	
H13	Horn	90980–10359
I 2	Ignition Coil and Igniter No.1	90980–11150
I 3	Ignition Coil and Igniter No.2	
I 6	IIA	90980–11037
I 7	IIA	90980–11038

G PART NUMBER OF CONNECTORS

Code	Part Name	Part Number
I 8	Intake Air Temp. Sensor (Except 2KD–FTV)	90980–11163
	Intake Air Temp. Sensor (2KD–FTV)	90980–11025
I 9	Injection Pump (1KZ–TE, 5L–E)	90980–11028
	Injection Pump (2L, 3L)	90980–11157
I10	Injector No.1 (1RZ–E)	90980–11285
	Injector No.1 (2KD–FTV)	90980–12005
	Injector No.1 (3RZ–FE, 2RZ–FE)	90980–11153
I11	Injector No.2 (1RZ–E)	90980–11285
	Injector No.2 (2KD–FTV)	90980–12005
	Injector No.2 (3RZ–FE, 2RZ–FE)	90980–11153
I12	Injector No.3 (1RZ–E)	90980–11285
	Injector No.3 (2KD–FTV)	90980–12005
	Injector No.3 (3RZ–FE, 2RZ–FE)	90980–11153
I13	Injector No.4 (1RZ–E)	90980–11285
	Injector No.4 (2KD–FTV)	90980–12005
	Injector No.4 (3RZ–FE, 2RZ–FE)	90980–11153
I15	ISC Valve	90980–11145
I16	Ignition Key Cylinder Light	90980–10906
I17	Ignition SW	90980–11615
I18	Integration Relay	90980–11121
I19	Integration Relay	90980–10799
I20	Interior Light	90980–10121
J 1	Junction Connector	90980–11661
J 2	Junction Connector	
J 3	Junction Connector (LHD)	90980–11661
	Junction Connector (RHD)	90980–10976
J 4	Junction Connector (LHD)	90980–11661
	Junction Connector (RHD)	90980–11542
J 5	Junction Connector (LHD)	90980–11661
	Junction Connector (RHD)	90980–11542
J 6	Junction Connector (LHD)	90980–11661
	Junction Connector (RHD)	90980–11542
J 7	Junction Connector (LHD)	90980–10976
	Junction Connector (RHD)	90980–11542
J 8	Junction Connector	90980–11542
J 9	Junction Connector (LHD)	90980–11542
	Junction Connector (RHD)	90980–10803
J10	Junction Connector	90980–11542
J11	Junction Connector	90980–10803
J12	Junction Connector	90980–11542
J13	Junction Connector (LHD)	90980–11542
	Junction Connector (RHD)	90980–11661
J14	Junction Connector (LHD)	90980–11542
	Junction Connector (RHD)	90980–11661

Code	Part Name	Part Number
J15	Junction Connector (LHD)	90980–10803
	Junction Connector (RHD)	90980–10976
J16	Junction Connector (LHD)	90980–10803
	Junction Connector (RHD)	90980–11661
J17	Junction Connector	90980–11661
J18	Junction Connector	90980–11542
J19	Junction Connector	
J20	Junction Connector	
J21	Junction Connector	90980–10803
J22	Junction Connector	
J23	Junction Connector	90980–10976
J25	Junction Connector	90980–10897
J26	Junction Connector	90980–11238
J27	Junction Connector	90980–10803
J28	Junction Connector	
K 1	Knock Sensor	90980–11166
L 1	License Plate Light LH (w/ Step Bumper Type)	90980–11162
	License Plate Light LH (w/o Step Bumper Type)	90980–11248
L 2	License Plate Light RH (w/ Step Bumper Type)	90980–11162
	License Plate Light RH (w/o Step Bumper Type)	90980–11248
N 1	Back–Up Light SW	90980–11332
	Neutral Start SW	
N 2	Noise Filter	90980–10843
O 1	Oil Pressure SW (Gasoline, 2KD–FTV, 1KZ–TE)	90980–11363
	Oil Pressure SW (2L,3L,5L–E)	90980–10703
O 2	A/T Shift Lever Illumination	90980–11614
	O/D Main SW	
O 5	Oil Monitor ECU	90980–12183
P 2	Parking Brake SW	90980–10825
P 3	Pre–Heating Timer	90980–10799
P 4	Personal Light	90980–10121
P 5	Power Window Control SW Front LH	90980–10789
P 6	Power Window Control SW Front RH	
P 7	Power Window Control SW Rear LH	
P 8	Power Window Control SW Rear RH	
P 9	Power Window Master SW (Double Cab)	90980–10807
	Power Window Master SW (Regular Cab, Extra Cab)	90980–10997
P10	Power Window Motor Front LH	90980–10860
P11	Power Window Motor Front RH	

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number
P12	Power Window Motor Rear LH	90980–10860
P13	Power Window Motor Rear RH	
P14	Pretensioner LH	90980–11862
P15	Pretensioner RH	
P16	Power Steering Oil Pressure SW	90980–11428
R 1	Radio and Player	90980–10997
R 2	Radio and Player	90980–10996
R 3	Rear Fog Light SW	90980–11533
R 4	Rear Window Defogger SW	90980–11326
R 5	Rheostat	90980–10214
R 6	Rear Combination Light LH (w/ Rear Deck)	90980–10173
	Rear Combination Light LH (w/o Rear Deck)	90980–10162
R 7	Rear Combination Light RH (w/ Rear Deck)	90980–10173
	Rear Combination Light RH (w/o Rear Deck)	90980–10162
R 8	Rear Diff. Lock Motor	90980–11194
R 9	Rear Fog Light (w/ Rear Deck)	90980–11140
	Rear Fog Light (w/o Rear Deck)	90980–11142
R10	Rear Window Defogger	90980–10359
R11	Rear Window Defogger	
R12	Remote Control Mirror LH (w/ Vent Window)	90980–11170
	Remote Control Mirror LH (w/o Vent Window)	90980–10907
R13	Remote Control Mirror RH (w/ Vent Window)	90980–11170
	Remote Control Mirror RH (w/o Vent Window)	90980–10907
R14	Remote Control Mirror SW	90980–11657
R15	Reverse Warning Buzzer	90980–11250
S 1	Speed Sensor (ECT)	90980–11156
S 2	Starter (Diesel)	90980–11184
	Starter (Gasoline)	90980–11400
S 3	Starter	
S 4	Stop Light SW	90980–11118
S 5	Seat Heater (Driver's Seat)	90980–10908
S 6	Seat Heater (Front Passenger's Seat)	
S 7	Seat Heater SW (Driver's Seat) (LHD)	90980–10795
	Seat Heater SW (Driver's Seat) (RHD)	90980–11090

Code	Part Name	Part Number
S 8	Seat Heater SW (Front Passenger's Seat) (LHD)	90980–11090
	Seat Heater SW (Front Passenger's Seat) (RHD)	90980–10795
S 9	Spill Control Valve	90980–11284
S10	Suction Control Valve	90980–11285
S11	Suction Control Valve No.2	90980–12005
S12	Speed Sensor (Combination Meter)	90980–11143
T 1	Throttle Position Sensor (1RZ–E, 1KZ–TE)	90980–10711
	Throttle Position Sensor (2RZ–FE, 3RZ–FE)	90980–11261
T 3	2–4 Select Motor	90980–11290
T 4	2–4 Select SW	90980–10355
T 5	Timing Control Valve (1KZ–TE)	90980–11285
	Timing Control Valve (5L–E)	90980–11038
T 6	Turbo Pressure Sensor	90980–10845
T 7	Transponder Key Amplifier	90980–10789
T 8	Transponder Key Computer	90980–11556
T 9	Throttle Open SW	90980–11156
T10	Throttle Control Motor (1KZ–TE)	90980–11194
	Throttle Control Motor (2KD–FTV, 5L–E)	90980–11144
U 1	Unlock Warning SW	90980–10795
V 1	Vacuum Sensor	90980–10845
V 2	Vacuum SW	90980–11163
V 3	Variable Resistor	90980–10902
V 4	VSV (2WD, ADD)	90980–11149
V 5	VSV (4WD, ADD)	90980–11156
V 6	VSV (A/C Idle–Up)	90980–10214
V 7	VSV (EGR)	90980–11162
V 8	VSV (EVAP)	90980–11156
V 9	VSV (Throttle Position Control)	90980–11149
V10	VRV (EGR)	90980–11162
V16	VSV (Pressure Charge Valve)	90980–11149
V17	VSV (Exhaust Gas Control)	90980–11156
W 1	Washer Motor	90980–11250
W 2	Water Temp. Sender	90980–11428
W 3	Water Temp. Sensor	90980–10737
W 4	Wiper Motor	90980–10171
W 5	Warm Up SW	90980–10996