
Position of Parts in Engine Compartment

[RHD : 5VZ–FE]



A 3 A/T Fluid Temp. Sensor
A 4 ABS Actuator
A 5 ABS Actuator
A 6 ABS Speed Sensor Front LH
A 7 ABS Speed Sensor Front RH
A 8 ADD Indicator SW
A 9 Air Flow Meter
A10 Alternator
A11 Alternator

B 1 Back–Up Light SW
B 2 Brake Fluid Level Warning SW

C 1 Camshaft Position Sensor
C 3 Check Connector
C 4 Crankshaft Position Sensor

D 1 Detection SW (Transfer 4WD Position)
D 2 Detection SW (Transfer L4 Position)
D26 Detection SW (Transfer Neutral Position)

E 1 ECT Solenoid

F 1 Front Clearance Light LH
F 2 Front Clearance Light RH
F 3 Front Side Turn Signal Light LH
F 4 Front Side Turn Signal Light RH
F 7 Front Turn Signal Light LH
F 8 Front Turn Signal Light RH
F15 Front Airbag Sensor LH
F16 Front Airbag Sensor RH

H 5 Headlight LH
H 6 Headlight RH
H 7 Heated Oxygen Sensor (Bank 1 Sensor 1)
H 9 Horn