ABBREVIATIONS USED IN THIS MANUAL

AAP	Auxiliary Acceleration Pump
A/C	Air Conditioner
APPROX.	Approximate
A/T	Automatic Transmission
BTDC	Before Top Dead Center
CB	Choke Breaker
CO	Choke Opener
DP	Dash Pot
ECU	Electronic Controlled Unit
EFI	Electronic Fuel Injection
EGR	Exhaust Gas Recirculation
ESA	Electronic Spark Advance
EX	Exhaust
Ex.	Except
FIPG	Formed in Place Gasket
HAI	Hot Air Intake
IIA	Integrated Ignition Assembly
IN	Intake
LH	Left-hand
MAX.	Maximum
MP	Multipurpose
M/T	Manual Transmission
OHC	Over Head Camshaft
O/S	Oversize
OVCV	Outer Vent Control Valve
PCV	Positive Crankcase Ventilation
PS	Power Steering
RH	Right-hand
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
TCCS	Toyota Computer Controlled System
TDC	Top Dead Center
TVSV	Thermostatic Vacuum Switching Valve
TWC	Three-Way Catalyst
U/S	Undersize
VTV	Vacuum Transmitting Valve
w/	With
w/o	Without