TROUBLESHOOTING

Problem	Possible cause	Remedy	Page
Oil leakage	Cylinder head, cylinder block or oil pump body damaged or cracked	Repair as necessary	
	Oil seal faulty	Replace oil seal	EM-99
	Gasket faulty	Replace gasket	
Low oil pressure	Oil leakage	Repair as necessary	
	Relief valve faulty	Replace relief valve	LU-11
	Oil pump faulty	Replace oil pump	LU-8
	Poor engine oil quality	Replace engine oil	LU-6
	Crankshaft bearing faulty	Replace bearing	EM-99
	Connecting rod bearing faulty	Replace bearing	EM-99
	Oil filter clogged	Replace oil filter	LU-6
High oil pressure	Relief valve faulty	Replace relief valve	LU-11