

FIRST AND REVERSE BRAKE
COMPONENTS

AT063-04





FIRST AND REVERSE BRAKE INSPECTION AT084-09

INSPECT DISC, PLATE AND FLANGE

Check to see if the sliding surface of the disc, plate and flange are worn or burnt. If nesessary, replace them.

HINT:

- If the lining of the disc is peeling off or discolored, or even if a part of the printed numbres are defaced, replace all discs.
- Before assembling new discs, soak them in ATF for at least 15 minutes.