PRECAUTION




CH00K–00

1. **Check that the battery cables are connected to the correct terminals.**
2. **Disconnect the battery cables when the battery is given a quick charge.**
3. **Do not perform tests with a high voltage insulation resistance tester.**
4. **Never disconnect the battery while the engine is running.**

PREPARATION

CH000–0X

SST (SPECIAL SERVICE TOOLS)

	09285–76010	Injection Pump Camshaft Bearing Cone Replacer	Rotor rear bearing cover
	09286–46011	Injection Pump Spline Shaft Puller	Rectifier end frame
	09820–00021	Alternator Rear Bearing Puller	Rotor rear bearing
	09820–00030	Alternator Rear Bearing Replacer	Rotor rear bearing
	09820–63010	Alternator Pulley Set Nut Wrench Set	
	09950–60010	Replacer Set	
	(09951–00240)	Replacer 24	Rotor front bearing
	(09951–00520)	Replacer 52	Rotor front bearing
	09950–70010	Handle Set	
	(09951–07100)	Handle 100	Rotor front bearing

RECOMMENDED TOOLS

CH00S–0T