IN

ABBREVIATIONS USED IN THIS MANUAL

IN0S1–0C

A/C	Air conditioner
BTDC	Before Top Dead Center
CB	Circuit Breaker
ECU	Electronic Control Unit
EFI	Electronic Fuel Injection
EVAP	Evaporative Emission
FIPG	Formed in Place Gasket
FL	Fusible Link
H–Fuse	High Current Fuse
IG	Ignition
IIA	Integrated Ignition Assembly
LH	Left–Hand
M–Fuse	Medium Current Fuse
MP	Multipurpose
O/S	Oversized
PCV	Positive Crankcase Ventilation
RH	Right–Hand
SST	Special Service Tools
SSM	Special Service Materials
STD	Standard
SW	Switch
TDC	Top Dead Center
VSV	Vacuum Switching Valve
w/	With
w/o	Without