# ABBREVIATIONS USED IN THIS MANUAL

IN031–GM



| | |
|---|---|
| A/C | Air conditioner |
| A/T | Automatic Transaxle |
| BTDC | Before Top Dead Center |
| CPU | Central Processing Unit |
| ECT | Electronic Controlled Transmission |
| ECU | Electronic Control Unit |
| EFI | Electronic Fuel Injection |
| EVAP | Evaporative Emission |
| FIPG | Formed in Place Gasket |
| H—Fuse | High Current Fuse |
| IG | Ignition |
| ISC | Idle Speed Control |
| LH | Light—Hand |
| M—Fuse | Medium Current Fuse |
| MP | Multipurpose |
| M/T | Manual Transaxle |
| O/S | Oversized |
| PCV | Positive Crankcase Ventilation |
| PS | Power steering |
| RH | Right—Hand |
| SST | Special Service Tools |
| STD | Standard |
| SW | Switch |
| TDC | Top Dead Center |
| TEMP. | Temperature |
| TWC | Three—Way Catalyst |
| U/S | Under size |
| VSV | Vacuum Switching Valve |
| w/ | With |
| w/o | Without |