

PREPARATION

SST (SPECIAL SERVICE TOOLS)

ST03P–0A

	09286–46011	Injection Pump Spline Shaft Puller	Armature bearing
	09810–38140	Starter Magnet Switch Nut Wrench 14	Terminal nut
	09201–41020	Valve Stem Oil Seal Replacer	Armature rear bearing

CST

RECOMMENDED TOOLS

ST03Q–09

	09082–00040	TOYOTA Electrical Tester.	

EQUIPMENT

ST03R–06

Dial indicator	Commutator
Magnetic finger	Steel ball
Pull scale	Brush spring
Sandpaper	Commutator
Torque wrench	
V–block	Commutator
Vernier calipers	Commutator, Brush
Press	Magnetic switch terminal kit

ON–VEHICLE INSPECTION

ST05K–0P

NOTICE: Before changing the starter, check the following items again:

- **Connector connection**
- **Accessory installation, e.g.: theft deterrent system**