PRECAUTION

CH00K-02




1. **Check that the battery cables are connected to the correct terminals.**
2. **Disconnect the battery cables when the battery is given a quick charge.**
3. **Do not perform tests with a high voltage insulation resistance tester.**
4. **Never disconnect the battery while the engine is running.**

PREPARATION

SST (SPECIAL SERVICE TOOLS)

CH000-19

CH

	09285−76010	Injection Pump Camshaft Bearing Cone Replacer	Rotor rear bearing cover for hi−speed compact type
	09286−46011	Injection Pump Spline Shaft Puller	Rectifier end frame for hi−speed compact type
	09820−00021	Alternator Rear Bearing Puller	Rotor rear bearing for hi−speed compact type
	09820−00030	Alternator Rear Bearing Replacer	Rotor rear bearing for hi−speed compact type
	09950−60010	Replacer Set	
	(09951−00180)	Replacer 18	Rotor for hi−speed compact type
	(09951−00230)	Replacer 23	Rotor front bearing for hi−speed compact type
	(09951−00340)	Replacer 34	Oil seal for hi−speed compact type
	(09951−00400)	Replacer 40	Rotor front bearing for hi−speed compact type
	09950−70010	Handle Set	
	(09951−07100)	Handle 100	Rotor, rotor front bearing, oil seal for hi−speed compact type