



# PREPARATION

## SST (SPECIAL SERVICE TOOLS)

ST00S-1D

| | | | |
|---|---|---|---|
|  | 09201–41020 | Valve Stem Oil Seal Replacer | Armature front bearing for 2.0 kW for LN Thailand |
|  | 09285–76010 | Injection Pump Camshaft Bearing Cone Replacer | Armature front bearing for 2.7 kW |
|  | 09286–46011 | Injection Pump Spline Shaft Puller | Armature bearing (Except rear bearing for 2.0 kW for LN Thailand) |
|  | 09810–38140 | Starter Magnet Switch Nut Wrench 14 | 2.0 kW |
|  | 09810–38170 | Starter Magnet Switch Nut Wrench 17 | 2.7 kW |
|  | 09820–00030 | Alternator Rear Bearing Replacer | Armature front bearing for 2.0 kW for Except LN Thailand |
|  | 09950–00020 | Bearing Remover | Armature rear bearing for 2.0 kW for LN Thailand |

## RECOMMENDED TOOLS

ST00T-14

| | | | |
|---|---|---|---|
|  | 09082–00040 | TOYOTA Electrical Tester. | |

## EQUIPMENT

ST00U-6W

| | |
|---|---|
| Dial indicator | Commutator |
| Heater | Water temperature Sensor |
| Magnetic finger | |
| Pull scale | Brush spring |
| Sandpaper | Commutator |
| Thermometer | Water temperature Sensor |
| Torque wrench | |
| V–block | |
| Vernier calipers | Commutator, Brush |