


STARTER PERFORMANCE TEST

ST010-1L


NOTICE: These tests must be performed within 3 to 5 seconds to avoid burning out the coil.

1. PERFORM PULL—IN TEST

(a) Disconnect the field coil lead wire from terminal C.


(b) Connect the battery to the magnetic switch as shown. Check that the clutch pinion gear moves outward.

ST




2. PERFORM HOLD—IN TEST

With battery connected as above with the clutch pinion gear out, disconnect the negative (—) lead from terminal C. Check that the pinion gear remains out.



3. INSPECT CLUTCH PINION GEAR RETURN

Disconnect the negative (—) lead from the switch body. Check that the clutch pinion gear returns inward.



4. PERFORM NO—LOAD PERFORMANCE TEST

(a) Connect the battery and ammeter to the starter as shown.

(b) Check that the starter rotates smoothly and steadily with the pinion gear moving out. Check that the ammeter shows the specified current.

Specified current at 11.0 V:

180 A or less

STARTER RELAY (LH, LJ)

STARTER RELAY INSPECTION

ST006-01

1. REMOVE STARTER RELAY

LOCATION: See relay locations in Electrical Wiring Diagram.