ABBREVIATIONS USED IN THIS MANUAL

IN031—0L

N

A/C	Air conditioner
AAP	Auxiliary Acceleration Pump
BTDC	Before Top Dead Center
BVSV	Bimetallic Vacuum Switching Valve
CB	Circuit Breaker
CO	Chock Breaker
DOHC	Double Over Head Cam
EX	Exhaust
FIPG	Formed in Place Gasket
FL	Fusible Link
H—Fuse	High Current Fuse
ECT	Electronic Controlled Transmission
ECU	Electronic Control Unit
EFI	Electronic Fuel Injection
IAT	Intake Air Temperature
MAF	Mass Air Flow Meter
PCV	Positive Crankcase Ventilation
IG	Ignition
IN	Intake
LH	Left—Hand
Max.	Maximum
M—Fuse	Medium Current Fuse
O/S	Oversize
OVCV	Outer Vent Control Valve
RH	Right—Hand
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
TEMP.	Temperature
TDC	Top Dead Center
TP	Throttle Positioner
U/S	Undersize
VSV	Vacuum Switching Valve
w/	With
w/o	Without