TERMS

ABBREVIATIONS USED IN THIS MANUAL

IN034-01

Abbreviations	Meaning
A/C	Air Conditioner
A/T	Automatic Transmission
BTDC	Before Top Dead Center
ECU	Electronic Control Unit
EFI	Electronic Fuel Injection
EGR	Exhaust Gas Recirculation
EVAP	Evaporative Emission Control
FIPG	Formed In Place Gasket
FL	Fusible Link
M/T	Manual Transmission
IG	Ignition
IIA	Integrated Ignition Assembly
ISC	Idle Speed Control
J/B	Junction Block
O/S	Oversize
PCV	Positive Crankcase Ventilation
SSM	Special Service Materials
SST	Special Service Tools
SW	Switch
TDC	Top Dead Center
TWC	Three – Way Catalyst
VSV	Vacuum Switching valve
w/	With
w/ o	Without
2WD	Two Wheel Drive Vehicles (4 x 2)
4WD	Four Wheel Drive Vehicles (4 x 4)