

STARTING

PP0LK–01

SST (Special Service Tools)

	09286–46011	Injection Pump Spline Shaft Puller	Armature bearing
	09810–38140	Starter Magnet Switch Nut Wrench 14	Terminal nut
	09820–00030	Alternator Rear Bearing Replacer	Armature rear bearing

PP0LL-01

RECOMMENDED TOOLS

	09082–00040 TOYOTA Electrical Tester.	

EQUIPMENT

PP0LM-01

Dial indicator	Commutator
Magnetic finger	Steel ball
Pull scale	Brush spring
Sandpaper	Commutator
Torque wrench	
V–block	Commutator
Vernier calipers	Commutator, Brush
Press	Magnetic switch terminal kit