DI1G9–01

# DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed for that code in the table below and proceed to the page given.

| DTC No. (See Page) | Detection Item | Trouble Area | O/D OFF Indicator Light Blink *1 | Memory *2 |
|---|---|---|---|---|
| P0500/42 (DI–25) | Vehicle Speed Sensor Malfunction (No.1 Vehicle Speed Sensor) | • Open or short in No.1 vehicle speed sensor circuit<br>• No.1 vehicle speed sensor<br>• Combination meter<br>• Engine & ECT ECU | ○ | ○ |
| P0710/38 (DI–25) | Transmission Fluid Temperature Sensor Malfunction (ATF Temperature Sensor) | • Open or short in ATF temperature sensor circuit<br>• ATF temperature sensor<br>• Engine & ECT ECU | ○ | ○ |
| P0753/62 (DI–29) | Shift Solenoid A Electrical Malfunction (No.1 Solenoid Valve) | • Open or short in shift solenoid valve No.1 circuit<br>• No.1 solenoid valve<br>• Engine & ECT ECU | ○ | ○ |
| P0758/63 (DI–29) | Shift Solenoid B Electrical Malfunction (No.2 Solenoid Valve) | • Open or short in shift solenoid valve No.2 circuit<br>• No.2 solenoid valve<br>• Engine & ECT ECU | ○ | ○ |
| P0773/64 (DI–33) | Shift Solenoid E Electrical Malfunction (SL Solenoid Valve) | • Open or short in shift solenoid valve SL circuit<br>• SL solenoid valve<br>• Engine & ECT ECU | X | ○ |
| P1700/61 (DI–37) | Vehicle Speed Sensor No.2 Malfunction (No.2 Vehicle Speed Sensor) | • Open or short in No.2 vehicle speed sensor circuit<br>• No.2 vehicle speed sensor<br>• Engine & ECT ECU | ○ | ○ |

*1: "○" mark means O/F OFF indicator light blinks once every 2 seconds.
"X"mark means O/F OFF indicator light never blinks.

*2: "○" mark means the Engine & ECT ECU memorizes the malfunction code if the Engine & ECT ECU detects the DTC detection condition.