DI18P-02

PROBLEM SYMPTOMS TABLE

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
• With the ignition switch at ACC or ON, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed. • SRS warning light is always lit up even when ignition switch is in the LOCK position.	• SRS warning light circuit (Always lights up when ignition switch is in LOCK position.)	DI–180
• With the ignition switch at ACC or ON, the SRS warning light does not light up.	• SRS warning light circuit (Does not light up when ignition switch is turned to ACC or ON.)	DI–183
• DTC is not displayed. • SRS warning light is always lit up in a DTC check procedure. • DTC is displayed without Tc and E1 terminal connection.	• Tc terminal circuit	DI–187