BODY ELECTRICAL

SST (Special Service Tools)

PP08Z–01

	09843–18020 Diagnosis Check Wire	

PP090–01

RECOMMENDED TOOLS

	09082–00050 TOYOTA Electrical Tester Set.	

PP091-01

EQUIPMENT

Voltmeter	
Ammeter	
Ohmmeter	
Test lead	
Thermometer	Engine coolant temperature sender gauge
Syphon	Brake fluid level warning switch
Oil bath	Engine oil level warning switch
Bulb (3.4 W)	Fuel sender gauge, Integration relay
Bulb (21 W)	Turn signal flasher relay
Dry cell battery	Fuel sender gauge, Power mirror
Torque wrench	
Clip remover	For removing cowl louver

PP052-01

SSM (Service Special Materials)

08833–00080	Adhesive 1344 THREE BOND 1344 LOCTITE 242 or equivalent	Low oil pressure warning switch Engine coolant temperature sender gauge