TROUBLESHOOTING

PROBLEM SYMPTOMS TABLE

PR01U-01

Symptom	Suspect Area	See page
Noise	1. Center support bearing (Worn)	PR–5 PR–14
	2. Sleeve yoke spline (Worn)	–
	3. Spider bearing (Worn or stuck)	PR–5 PR–14
Vibration	1. Transmission extension housing rear bushing (Worn)	–
	2. Sleeve yoke spline (Stuck)	–
	3. Propeller shaft (Runout)	PR–5 PR–14
	4. Propeller shaft (Imbalance)	–