TROUBLESHOOTING

PROBLEM SYMPTOMS TABLE

SR096-01

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in the order shown. If necessary, repair or replace these parts.

Symptom	Suspect Area	See page
Hard steering	1. Tires (Improperly inflated)	SA–4 SA–6
	2. Power steering fluid level (Low)	SR–6
	3. Drive belt (Loose)	SR–3
	4. Front wheel alignment (Incorrect)	SA–8 SA–12
	5. Steering system joints (Worn)	–
	6. Suspension arm ball joints (Worn)	–
	7. Steering column (Binding)	SR–13
	8. Power steering vane pump	SR–27 SR–37 SR–47 SR–57 SR–67
	9. Steering gear	SR–77 SR–89 SR–101 SR–114
Poor return	1. Tires (Improperly inflated)	SA–4 SA–6
	2. Front wheel alignment (Incorrect)	SA–8 SA–12
	3. Steering column (Binding)	SR–13
	4. Steering gear	SR–77 SR–89 SR–101 SR–114
Excessive play	1. Steering system joints (Worn)	–
	2. Suspension arm ball joints (Worn)	–
	3. Intermediate shaft, Sliding yoke (Worn)	SR–13
	4. Front wheel bearing (Worn)	–
	5. Steering gear	SR–77 SR–89 SR–101 SR–114
Abnormal noise	1. Power steering fluid level (Low)	SR–6
	2. Steering system joints (Worn)	–
	3. Power steering vane pump	SR–27 SR–37 SR–47 SR–57 SR–67
	4. Steering gear	SR–77 SR–89 SR–101 SR–114

SR