# CATALYTIC CONVERTER FOR OXIDATION (CCo) SYSTEM

EC09S–01

## ON–VEHICLE INSPECTION

**1. INSPECT EXHAUST PIPE ASSEMBLY**

(a) Check the connections for looseness or damage.

(b) Check the clamps for weakness, cracks or damage.

**2. INSPECT CCo**

Check for dents or damage.

If any part of the protector is damaged or dented to the extent that it contacts the CCo, repair or replace it.

**3. INSPECT CCo HEAT INSULATOR**

(a) Check the heat insulator for damage.

(b) Check for adequate clearance between the CCo and heat insulator.