DI164–27

PROBLEM SYMPTOMS TABLE

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
• With the ignition switch in ACC or ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed.	• SRS warning light circuit	DI–48
• SRS warning light is always lit up even when ignition switch is in the LOCK position.		
• With the ignition switch in ACC or ON position, the SRS warning light does not light up.		
• DTC is not displayed.	• Tc terminal circuit	DI–53
• SRS warning light is always lit up at the time of DTC check procedure.		
• DTC is displayed without Tc and E1 terminal connection.		