STEERING

TORQUE SPECIFICATION

SS0AV–06

Part tightened	N·m	kgf·cm	ft·lbf
STEERING COLUMN			
Non–tilt steering column:			
Column tube support x Column tube	20	204	15
Tilt steering column:			
Tilt lever assembly set bolt	12	125	9
Tilt support No.1 reinforce set bolt	5.4	55	48 in.·lbf
Steering support x Column tube	9.5	97	84 in.·lbf
Sliding yoke x Main shaft assembly	35	360	26
Steering column assembly set bolt and nut	26	260	19
Sliding yoke x No.2 intermediate shaft assembly	35	360	26
No.2 intermediate shaft assembly x Worm assembly 2WD	35	360	26
No.2 intermediate shaft assembly x Worm gear valve body assembly 4WD	35	360	26
Sliding with shaft yoke x No.2 intermediate shaft assembly	35	360	26
Column hole cover	8	80	69 in.·lbf
Steering wheel set nut	34	350	25
Steering wheel pad set screw (Torx screw)	9.0	90	78 in.·lbf