








MANUAL TRANSMISSION (R151F)

PP3E8–01

SST (Special Service Tools)

	09316–60011	Transmission & Transfer Bearing Replacer	
	(09316–00011)	Replacer Pipe	Output shaft rear bearing Gear spline piece No.5
	(09316–00031)	Replacer "B"	5th gear
	(09316–00071)	Replacer "F"	Output shaft rear bearing Output shaft center bearing
	09506–35010	Differential Drive Pinion Rear Bearing Replacer	Input shaft bearing
	09950–00020	Bearing Remover	
	09950–40011	Puller B Set	Output shaft rear bearing
	09950–50012	Puller C Set	Gear spline piece No.5
	09950–60010	Replacer Set	
	(09951–00510)	Replacer 51	Front bearing retainer oil seal
	(09951–00570)	Replacer 57	Extension housing oil seal Transfer adaptor oil seal
	(09951–00620)	Replacer 62	Counter rear bearing

	09950–70010 Handle Set	
	(09951–07150) Handle 150	