FIRST GEAR POSITION SWITCH (M/T)

ED03Y–01

INSPECTION

INSPECT FIRST GEAR POSITION SWITCH

(a) Disconnect the switch connector.

(b) Using an ohmmeter, check the switch continuity.

Continuity:

Transmission Shift Position	Specified continuity
1	Continuity
Others	No continuity

If the continuity is not as specified, replace the switch.

(c) Reconnect the switch connector.