ED03Z–01

REPLACEMENT

1. REMOVE TRANSMISSION

2. REMOVE FIRST GEAR POSITION SWITCH

(a) Using SST, remove the switch and gasket.
SST 09817–16011

(b) Remove the gasket from the switch.

3. REINSTALL NEW FIRST GEAR POSITION SWITCH

(a) Install a new gasket to the switch.

(b) Using SST, install the switch.
Torque: 30 N·m (306 kgf·cm, 22.1 ft·lbf)
SST 09817–16011

4. REINSTALL TRANSMISSION