PP1TR–04

EQUIPMENT

Dial indicator	Impeller wheel
Torque wrench	