PP1FL–04

EQUIPMENT

Injection nozzle tester	
Injection pump tester	
Torque wrench	
19 mm deep socket wrench	Fuel temperature sensor