CYLINDER BLOCK

EM1MM–01

DISASSEMBLY

REMOVE CRANK POSITION SENSOR

(a) Disconnect the connector.
(b) Remove the bolt, crank position sensor.