EM1MN–01

REASSEMBLY

INSTALL CRANK POSITION SENSOR

(a) Install a new O–ring and crank position sensor with bolt.
Torque: 5 N·m (51 kgf·cm, 4 ft·lbf)

(b) Connect the connector.