


FU2702


FU2728

FU00U–03

TEST

1. INJECTION PRESSURE TEST

(a) Install the injection nozzle to the injection nozzle hand tester and bleed air from the union nut.

CAUTION:

Do not plate your finger over the nozzle injection hole.

(b) Pump the tester handle a few times as fast as possible to discharge the carbon from the injection hole.

(c) Pump the tester handle slowly and observe the pressure gauge.

(d) Read the pressure gauge just as the injection pressure begins to drop.

Opening pressure:
new nozzle
15,790 – 16,570 kPa
(161 – 169 kgf/cm^2, 2,290 – 2,404 psi)
Reused nozzle
15,200 – 16,180 kPa
(155 – 165 kgf/cm^2, 2,205 – 2,347 psi)

HINT:

Proper nozzle operation can be determined by a switching sound.

If the opening pressure is not as specified, disassemble the nozzle holder and change the adjusting shim on the top of the pressure spring.


Adjusting opening pressure
15,200 – 16,180 kPa
(155 – 165 kgf/cm^2, 2,205 – 2,347 psi)
Adjusting shim thickness:

0.900(0.0354)	1.300(0.0512)	1.700(0.0669)
0.950(0.0374)	1.350(0.0531)	1.750(0.0689)
1.000(0.0394)	1.400(0.0551)	1.800(0.0709)
1.050(0.0413)	1.450(0.0571)	1.850(0.0728)
1.100(0.0433)	1.500(0.0591)	1.900(0.0748)
1.150(0.0453)	1.550(0.0610)	1.950(0.0768)
1.200(0.0472)	1.600(0.0630)	–
1.250(0.0492)	1.650(0.0650)	–

HINT:

- Varying the adjusting shim thickness by 0.05 mm (0.0020 in.) changes the injection pressure by about 628 kPa (6.4 kgf·cm^2, 91 psi)
- Only one adjusting shim should be used.


(e) There should be dripping after injection.



2. LEAKAGE TEST

While maintaining pressure at about 981 – 1,961 kPa (10 – 20 kgf·cm^2, 142 – 284 psi) below opening pressure (adjust by tester handle), check that there is no dripping for 10 seconds from the injection hole or around the retaining nut.

If the nozzle drips with in 10 seconds, replace or clean and overhaul the nozzle assembly.



3. SPRAY PATTERN TEST

(a) The injection nozzle should shudder at a certain pumping speed between 15 – 60 times (old nozzle) or 30 60 times (new nozzle) per minute.

(b) Check the spray pattern during shuddering.

If the spray pattern is not correct during shuddering, the nozzle must be replaced or cleaned.