
CO0WN–03




INSPECTION

1. INSPECT WATER PUMP

(a) Visually check the water hole for coolant leakage.
If leakage is found, replace the water pump.

(b) Turn the pulley and check that the water pump bearing moves smoothly and quietly.

If necessary, replace the water pump.



2. INSPECT FLUID COUPLING

Check the fluid coupling for damage and silicon oil leakage.
If necessary, replace the fluid coupling.