CATALYTIC CONVERTER FOR OXIDATION (CCo) SYSTEM

EC0CW–01

ON–VEHICLE INSPECTION

1. **CHECK CONNECTIONS FOR LOOSENESS OR DAMAGE**
2. **CHECK CLAMPS FOR WEAKNESS, CRACKS OR DAMAGE**
3. **CHECK FOR DENTS OR DAMAGE**

If any part of the protector is damaged or dented to the extent that it contacts the CCo, repair or replace it.

4. **CHECK HEAT INSULATOR FOR DAMAGE**
5. **CHECK FOR ADEQUATE CLEARANCE BETWEEN CATALYTIC CONVERTER AND HEAT INSULATOR**