ED04F–01

INSPECTION

1. REMOVE EDU

(a) Disconnect the 2 connectors.

(b) Remove the 2 bolts and EDU.

2. INSPECT EDU (See page DI–108)

3. INSTALL EDU

(a) Install the EDU with the 2 bolts.

(b) Connect the 2 connectors.