LU0PB–01

DISASSEMBLY

1. REMOVE DRIVEN ROTOR

2. REMOVE NO. 1 STRAIGHT SCREW PLUG

Remove the plug and gasket.

3. REMOVE RELIEF VALVE

Remove the plug, gasket, spring and relief valve.