DI9SR–01

DTC	13	Crankshaft Position Sensor Circuit (During engine running)

CIRCUIT DESCRIPTION

Refer to DTC 12 on page DI–180.

DTC No.	DTC Detection Condition	Trouble Area
P1335/13	If conditions (a) through (c) are met: (a) NE ≧ 1,000 rpm (b) NE signal is not detected for over 50 msec. (c) Not during cranking	• Open or short in crankshaft position sensor circuit • Crankshaft position sensor • Signal plate • Engine ECU

WIRING DIAGRAM

Refer to DTC 12 on page DI–180.

INSPECTION PROCEDURE

Refer to DTC 12 on page DI–180.