POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM


EC0LN–01

INSPECTION

1. REMOVE PCV VALVE

(a) Disconnect the PCV hose from the PCV valve.

(b) Remove the PCV valve.




2. INSTALL CLEAN HOSE TO PCV VALVE

3. INSPECT PCV VALVE OPERATION

(a) Blow air into the cylinder head side, and check that air passes through easily.

CAUTION:

Do not suck air through the valve. Petroleum substances inside the valve are harmful.




(b) Blow air into the intake manifold side, and check that it has a little difficulty for the air to pass through.

If operation is not as specified, replace the PCV valve.

4. REMOVE CLEAN HOSE FROM PCV VALVE

5. REINSTALL PCV VALVE



6. INSPECT HOSES, CONNECTIONS AND GASKETS

Visually check for cracks, leaks or damage.