AC3NJ–01

# REMOVAL

**1. RUN ENGINE AT IDLE SPEED WITH A/C ON FOR APPROX. 10 MINUTES**

**2. STOP ENGINE**

**3. DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY**

**4. DISCHARGE REFRIGERANT FROM REFRIGERATION SYSTEM**

**5. REMOVE DRIVE BELT**

**6. DISCONNECT DISCHARGE AND SUCTION HOSES**

Remove the 2 nuts and disconnect the both hoses.

**NOTICE:**

**Cap the open fittings immediately to keep moisture or dirt out of the system.**

**7. REMOVE COMPRESSOR**

(a) Disconnect the connector.

(b) Remove the 4 bolts and compressor.