BR0G3–03

INSTALLATION

Installation is in the reverse order of removal (See page BR–17).

AFTER INSTALLATION, CHECK SPEED SENSOR SIGNAL (See Pub. No. RM585E on page DI–52)