BR0G6–03

INSTALLATION

Installation is in the reverse order of removal (See page BR–20).
AFTER INSTALLATION, CHECK SPEED SENSOR SIGNAL (See Pub. No. RM585E on page DI–52)