MT0GK–01

INSTALLATION

Installation is in the reverse order of removal (See page MT–2)

HINT:

After installation, do the road test.